

# Blum 155 Degree Special Application Hinge for Face Frame Overlay Cabinets

## HOW TO CHOOSE THE CORRECT MOUNTING PLATE

<b>STEP 1</b>	<b>Measure your bore distance.</b> This is the distance from the edge of the door to the edge of the large round hole drilled into the back of the door.
<b>STEP 2</b>	<p><b>Measure your door overlay.</b> The overlay is how much the door overlaps the cabinet. The following directions will tell you how to measure it. For further clarification, there is a link on the product page with more detailed instructions.</p> <ol style="list-style-type: none"> <li style="background-color: #e67e22; color: white; padding: 2px 5px; display: inline-block; margin-bottom: 5px;">1</li> Close the cabinet door. <li style="background-color: #e67e22; color: white; padding: 2px 5px; display: inline-block; margin-bottom: 5px;">2</li> Apply a piece of tape vertically to the hinged side of the cabinet so the edge of the tape is flush against the hinged edge of the door. This marks how much the door overlaps the frame. <li style="background-color: #e67e22; color: white; padding: 2px 5px; display: inline-block; margin-bottom: 5px;">3</li> Open the door until you see the edge of the tape between the door and cabinet. Measure from the inside edge of the tape to the opening of the cabinet door. This is your overlay dimension. </ol>
<b>STEP 3</b>	<p>Once you know the bore distance and overlay of your door, you can use the chart below to determine which mounting plate you need. If you find that the chart gives you two mounting plate options, choose the plate where your overlay is closest to the middle of the range shown. This will give you the largest range of adjustment.</p> <p>Example: if your overlay is 16mm and your bore distance is 6mm, then you have the option of choosing either the 3mm plate or the 0mm plate. While either will work, the best choice would be the 0mm plate because it provides slightly more room for adjustment.</p>

APPOXIMATE CONVERSION CHART	
3mm	1/8"
4mm	5/32"
5mm	3/16"
5.5mm	7/32"
6mm	1/4"
7mm	9/32"
8mm	5/16"
9mm	11/32"
9.5mm	3/8"
10mm	13/32"
11mm	7/16"
12mm	15/32"
13mm	1/2"
13.5mm	17/32"
14mm	9/16"
15mm	19/32"
16mm	5/8"
17mm	11/16"
18mm	23/32"
19mm	3/4"
20mm	25/32"
20.5mm	7/8"
21mm	27/32"
22mm	7/8"
23mm	29/32"
24mm	15/16"
25.4mm	1"
26mm	1-1/32"
27mm	1-1/16"
28mm	1-3/32"
29mm	1-1/18"
30mm	1-3/16"
31mm	1-7/32"
32mm	1-1/4"
33mm	1-5/16"
34mm	1-11/32"
35mm	1-3/8"

		BORE DISTANCE					
		3MM	4MM	5MM	6MM	7MM	8MM
OVERLAY RANGE	9MM TO 13MM	3mm Plate (SKU 652305)					
	10MM TO 14MM		3mm Plate (SKU 652305)				
	11MM TO 15MM			3mm Plate (SKU 652305)			
	12MM TO 16MM	0mm Plate (SKU 652304)			3mm Plate (SKU 652305)		
	13MM TO 17MM		0mm Plate (SKU 652304)			3mm Plate (SKU 652305)	
	14MM TO 18MM			0mm Plate (SKU 652304)			3mm Plate (SKU 652305)
	15MM TO 19MM				0mm Plate (SKU 652304)		
	16MM TO 20MM					0mm Plate (SKU 652304)	
	17MM TO 21MM						0mm Plate (SKU 652304)